

IGNITION SWITCH



3. Disconnect harness connector.
4. Remove relay on dash side.
5. Install relay in the reverse order of removal.

INSPECTION



IGNITION AND ACCESSORY RELAY

REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Remove instrument lower cover on the right side.

COMBINATION SWITCH

REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Remove horn pad.
3. Remove steering wheel.
4. Remove steering column cover.
5. Disconnect combination switch wires at connector.
6. Loosen retaining screw and remove combination switch assembly.
7. Install combination switch in the

INSPECTION

Test continuity through switch with a test lamp or ohmmeter.

